



Contemporary
Lighting™

PRODUCT NAME:Wand LED Bath Vanity

ITEM NUMBER:E22391,E22392,E22393,E22394

Assembly Instructions

1. Pull the power supply wires out from the outlet box and mount the universal mounting plate to the outlet box using mounting screws.
2. Place the base onto the fixture over the outlet box and tighten with the Finials (2Pcs).

Electrical Wiring

With wire connectors,connect powercords from outlet box to fixture.

- Smooth/Black wire to Black wire
- Ribbed/White wire to White wire
- Green to Ground

Please consult a qualified Electrician if you are not familiar with electrical wiring.

